



Threadless Embroidery

Created by Amanda Whitlatch

Jump “write” into PaintWork and CrystalWork with the BERNINA Exclusive Scrollwork Alphabet Design Collection #21007DW

Supplies

Machine & Accessories

- Compatible BERNINA Embroidery Machine
- Universal Stitch Plate for DesignWorks
- BERNINA PaintWork Tool & Pens
- BERNINA CrystalWork & CutWork Tools
- Scrollwork Alphabet #21007DW Collection

Notions

- CrystalWork: Parchment Paper, Backing Board, Template Material, Transfer Tape & SS6 Crystals
- OESD StabilStick Stabilizer
- Blank Greeting Card
- Napkin, Placement, or project of your choice.
- 4.5" x 9" piece of 1/8" thick Balsa or Craft Wood (or laminate 2-1/16" pieces) for Door Hanger.



Napkin and Note Card Projects

- Hoop StabilStick Stabilizer, score and remove the paper to reveal the sticky surface.
- Place the napkin on the stabilizer and smooth.
- Load the designs onto the embroidery machine and check the design placement.
- Paint the design onto the project.
- Remove the project and apply the Crystal Transfer

Crystal Transfer

- Hoop Parchment Paper on TOP OF HOOP.
- Apply Template Material to the center of the hoop.
- Load Crystal Design and punch the design.
- Remove the Template Material and stick to a piece of Backing Board and trim the edges even.
- Place crystals onto the template and brush gently or shake the crystals into place.
- Brush off all excess and apply the Transfer Tape.
- Peel up and apply over the PaintWork letter.
- Repeat the process for the second color.

Door Hanger Project

- Hoop StabilStick Stabilizer, score and remove the paper to reveal the sticky surface.
- Center the wood in the hoop and load the desired design onto the machine.
- Check the design placement centering the design in the bottom most area of the wood piece.
- Paint the design onto the project.
- Remove the PaintWork Tool and insert the Cut-Work Tool.
- Download the Door Hanger Design included with this project sheet available bernina.com and load the design onto the machine.
- Check the design placement making sure the Painted letter is centered at the bottom of the CutWork design.
- Turn the blade to position 1 and Start.
- Complete the design with blade positions 2, 3 & 4.
- Remove the completed project from the hoop.

Visit bernina.com
for additional DesignWorks projects!