

# SUPER SEW DAY

# Sew Caddy Stitching Instructions



## SUPPLIES:

Exterior - Duck Cloth- 1 piece 15" x 20"  
 Interior Lining- cotton fabric- 1 piece 15" x 20"  
 Pockets- cotton fabric - 1 piece 10" x 12" and 1 piece 10" x 5"  
 Stabilizer- Heavyweight CutAway Stabilizer -2 pieces 20" x 15"  
 Twill Tape Tie- 1 piece 20" in length  
 OESD Embroidery Tape Tear Away  
 Peel N Stick Ruler Tape  
 Isacord Embroidery Thread  
 Superior Threads Bottom line 60wt thread

BERNINA 880 PLUS

Jumbo Hoop

Drop-Shaped Embroidery Foot #26

Touchscreen pen (stylus)

Edgestitch Foot #10D

Embroidery needle (Schmetz Embroidery 75 or Organ Titanium Sharp 80)

## INSTRUCTIONS:

### Preparing to stitch the Sew Caddy

#### B 880 Machine Settings

*NOTE: Check to make sure that the Embroidery Settings for Automatic cut/ Jump stitch length are changed from the default of 6mm to 1mm.*



Preparing the pocket pieces.

Fold and press the 10" x 5" piece-

Fold in half lengthwise (like a hot dog bun) wrong side together and press. It will now be 10"x2.5.



# SUPER SEW DAY

## Sew Caddy Stitching Instructions

Fold and press the piece that is 10" x 12"-

Measure up 2 1/2" from the lower edge, fold and press wrong sides together.


Measure up 3 1/2" from the opposite edge, fold and press wrong side together up 3 1/2".



Where the raw edges meet, fold back the narrower section onto the wider so that both raw edges are now together on either side of the fold just created.



This is a double pocket.




Hoop the Duck Cloth and HeavyWeight CutAway stabilizer in the Jumbo Hoop.



At the B 880 PLUS embroidery machine

Select *Embroidery Mode* on the Home Screen



Attach the Jumbo Hoop onto the B 880.

### Sew Caddy Exterior Stitching

From the Folder menu, touch My Designs folder

Touch the "01-CLExteriorSC"



# SUPER SEW DAY

## Sew Caddy Stitching Instructions


Touch *Information* icon




Touch *Move*

Touch on screen or use the Upper and Lower Multi-function knobs to move the design into the stitchable area of the hoop.

Close *Information*




Touch *OK* (needle icon) to open *Sewing Stitches*.




Start stitching



When stitching is complete, touch the *Flag* and touch *Edit*.



Position the *Peel & Stick Ruler Tape* in the center of the hoop.






# SUPER SEW DAY

## Sew Caddy Stitching Instructions


### Touch *Add*




Touch the "02-Design-SC-SB "



Touch the *Information* icon and touch *Pinpoint Placement*.



### Touch *Grid*




Touch the top center dot.

Move the design to approximately 5 3/4" on the ruler tape for vertical placement.

Move horizontally so the "w" and "C" are approximately 1 grid off of the vertical center.


Use the *Upper and Lower Multi-function knobs* to position the needle at the point of the hooped project.



Use the hand wheel to lower the needle to check the placement. Raise the needle back to the highest point after you have finished checking.

# SUPER SEW DAY


## Sew Caddy Stitching Instructions



When the needle is positioned correctly at the correct point, touch *Set* on the screen of the machine to confirm. You will see that the dot now has a yellow highlight around it.

Touch the bottom center dot.


Touch *Set* to confirm placement. No adjustment should be needed. You will see that the dot now has a yellow highlight around it. Touch "i" in the breadcrumbs to return to the Information menu.




Move the *Peel & Stick Ruler Tape* to the top of the hoop so that you will not stitch on it.



Touch *Layer Panel 1* the Cutting Line that has already been stitched, touch *Delete*



Touch *Confirm*




# SUPER SEW DAY

## Sew Caddy Stitching Instructions

### Close Information

Touch OK (needle icon) to open *Sewing Stitches*



Touch *Color Resequence* to combine the identical color sequences and prevent the machine from stopping between each of the stitches in the border design.


*Automatic Thread Cut* between stitches is selected. Start the stitching, changing thread colors as prompted if desired.



When the machine stops, prior to stitching the "Stitch Border" design, touch *Automatic Thread Cut* to deactivate. Continue stitching the remainder of the design.



Touch the *Flag* and touch *Edit*



Re-position the *Peel & Stick Ruler Tape* in the center of the hoop






# SUPER SEW DAY

## Sew Caddy Stitching Instructions


Touch *Add*



Touch "03-Design SM-TL"




Touch *Information*



Touch *Layer Panel 2*, scroll and touch *Pinpoint Placement*


Touch *Grid*



Touch the bottom center dot, move the design down so that the bottom of the design is at 6 3/4" on the ruler tape or approximately two grid squares below horizontal hoop center shown on screen.

Use the *Upper and Lower Multi-function knobs* to position the needle at the point. Use the hand wheel to lower the needle to check the placement. Raise the needle back to the highest point after you have finished checking.

Touch *Set* on the screen of the machine to confirm. You will see that the dot now has a yellow highlight around it.




# SUPER SEW DAY


## Sew Caddy Stitching Instructions

Touch the top center dot. There should be no need for adjustment, touch Set to confirm placement. You will see that the dot now has a yellow highlight around it

Touch "i" in the breadcrumbs to return to the *Edit* menu.



Remove the *Peel & Stick Ruler Tape* and save it for later. Touch *Layer Panel 1 "02-Design SC-SB"*, touch *Delete*.




Touch *Confirm* to delete.



Close *Information*

The design is ready to stitch.

Touch OK (needle icon) to open *Sewing Stitches*



The *Thread Cut* is activated.

*Color Resequencing* if available should be activated.

(This is to combine the identical color sequences and prevent the machine from stopping between stitches.)






# SUPER SEW DAY

## Sew Caddy Stitching Instructions

After the center medallion has finished stitching, touch the *Thread Cut* to deactivate for stitching the remainder of the design.



Stitch the design.



When stitching is complete, remove from the hoop. Set it to the side to trim later.

### Sewing Caddy Interior (Lining) Stitching


Hoop the lining fabric and Heavyweight Cutaway stabilizer in the Jumbo Hoop.

NOTE: If using the *Contempo Sewing Room Fabric* by Amanda Murphy, place the fabric into the hoop so that the machines are upside down. When the sewing caddy is complete and the caddy is opened the machines will be viewed right side up!




Attach the Jumbo Hoop to the B 880.

Touch the *Flag* and touch *Edit*



Touch *Selection* and



# SUPER SEW DAY

## Sew Caddy Stitching Instructions


Touch *New Motif*



Touch *04-SC-Interior-All* design



Touch *Information*



Scroll and touch *Group*



Touch *Ungroup*



The ungrouped interior design shows the order of the stitching.

First the cutting line and pocket placement is stitched. Followed by pocket tack down stitching, pocket divider stitching, tie placement and tie tack down, and last the seam allowance stitching to complete the In the Hoop project.

# SUPER SEW DAY


## Sew Caddy Stitching Instructions

Touch *Close Information*



Ready to stitch the sew caddy interior.


Touch *OK* (needle icon) to open *Sewing Stitches*.



Touch *Thread Cut* to activate.




Stitch cutting line and pocket placement line.



Position the prepared pockets raw edges even with the stitched placement line and upper stitched cutting line. Place a piece of the OESD Embroidery Tear Away Tape the length of both edges of the pockets raw edges. This will keep the edges from getting caught and folded over as the machine is stitching the pocket tack down stitching.

NOTE: Removing the hoop from the machine may make this easier, be sure and work on a flat surface.



Attach the hoop to the machine.

Begin stitching the pocket tack down stitches. The last stitching is the satin stitching to finish the interior raw edge of the pocket.



# SUPER SEW DAY

## Sew Caddy Stitching Instructions




*NOTE: While the pocket stitching is in process, now is a good time to trim the exterior sew caddy at the stitched cutting line, don't cut the line of stitching.*

The last stitching is the satin stitching to finish the interior raw edge of the pocket.



Stitch the pocket dividers.




When pocket dividers have finished stitching the next thing to stitch will be the placement line for the twill tie.

Stitch the placement line.

Fold the tie in half **right sides together**.

Position twill tie vertically on top of the stitched placement line with the tails of the tie inside the hoop stitching area. Secure using a piece of OESD Tear Away tape.



# SUPER SEW DAY

## Sew Caddy Stitching Instructions

Stitch the tie tackdown stitching.



Stitching the exterior and interior together

Trim the exterior sew caddy cover close to the stitched cutting line.



Carefully remove the Jumbo hoop from the machine, DO NOT unhoop the lining. Place on a flat surface.

Right sides together, position the sew caddy on top of the hooped lining and pockets.


Line up the edge of the sew caddy cover with the cutting line stitched on the hooped lining.

Use the Tear Away tape to hold in position as the seam line is stitched.



Attach the Jumbo hoop to the machine.

Begin stitching the perimeter seam.




Remove the project from the hoop. Trim along the cutting line and edge of exterior.

# SUPER SEW DAY

## Sew Caddy Stitching Instructions

Trim corners and clip the curve of the flap.



Turn caddy right side out, carefully, a point turner or OESD Expert Point & Press Tool really works great to smooth edges and define points. Press with an iron, press the open edges in the width of the seam allowance.



### Finishing the Sew Caddy

Touch Home



Touch Sewing Mode



Change Needle Plate to the 9mm if you have the Straight Stitch 0mm plate on for embroidery.

Attach the #10D Edgestitch Foot and engage the Dual Feed.

Adjust needle position to -3. Adjust the SL to 2.75





# SUPER SEW DAY

## Sew Caddy Stitching Instructions

Stitch along the straight and open end of the caddy.

If desired, Edgestitch around all sides of the Sew Caddy for a nice finished look.

