

Jacket "Timo"

Model 123-30

Sizes 48–58



PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter). (Do not click on "Adjustment to page size"!))
2. Check the square – if it is 10×10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size. (The overview of the cut parts is on the pattern sheet.)

Important: Instructions do not include seam allowances, unless otherwise indicated!

SUPPLIES

- 1.8–2.1 m linen, 140 cm wide
- 10 buttons, 20 mm
- Woven interlining G 700 (Vlieseline)
- Seam tape
- [Overlocker BERNINA L 890](#)
- [Button Sew-On Foot #18](#)

CUTTING

Cut the paper piece 5 apart along the horizontal line.

- 1 2× front part
- 2 2× button placket
- 3 4× flap
- 4 4× shoulder strap
- 5 2× rear yoke on the fold
- 5 1× back part on the fold
- 6 2× collar on the fold
- 7 2× sleeve

2 breast pockets: Width 14 up to 16× height 16 up to 19 cm.

INSTRUCTIONS

1. Iron the interlining on the button plackets, one collar part, two flaps and two shoulder straps. Iron the seam tape on the lower edge of the yoke and the armholes.
2. Hem the upper edges of the pockets. Iron the remaining allowances to the wrong side. Topstitch the pockets onto the front part according to the marking.
3. Place one reinforced and one plain flap part right side on right side on top of each other and sew them together along the sides and the lower edge. Trim the allowances and turn the flap inside out.
4. Sew the shoulder straps in the same way, also leaving the short narrow edge open. Topstitch the pieces all around. Sew the flaps centrally above the pockets at a distance of approx. 1 cm.



made to create **BERNINA**

INSTRUCTIONS

5. Pin one yoke part right side on right side along the upper edge of the back part, the second right side on wrong side. Sew on the yokes, clip the allowances along the curves and cut them back at the tips. Iron the yokes upwards and topstitch them once at a narrow distance and once at a wider distance from the edge.
6. Close the shoulder seams of the front part and the outer yoke. Fix the shoulder seam of the inner yoke with the allowance folded in with pins. Topstitch the outer yoke 2× from the right, also stitching the inner yoke. Pin the shoulder straps centrally above the seams and topstitch them on the allowances.
7. Close the side seams. Sew the button plackets right side on right side along the front part. Iron the allowance towards the placket, iron the allowance of the other long edge and pin it over the inside of the placket seam. Topstitch the placket from the right, ending about 10 cm in front of the hem line.
8. Sew the upper and the narrow edges of the collar right side on right side together and turn it inside out. Sew the outer collar right side on right side to the front part. Pin the inner collar with the allowances folded in and topstitch it all around from the right.
9. Close the sleeve seams. Slightly gather the top shaping and sew in the sleeves. Hem the jacket and the sleeves. Sew the buttonholes at a distance of approx. 10 cm and sew on the buttons with the presser foot #18.



made to create **BERNINA**