

Bag "Klara"

Model 7512
Size 29 x 32 cm



PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter) (do not click on "Adjustment to page size"!)
2. Check the square – if it is 10x10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size (the overview of the cut parts is on the pattern sheet). **Important:** Instructions do not include seam allowances, unless otherwise indicated.

SUPPLIES

- 0.5 m Imitation leather, 140 cm wide
- 1 Magnetic clasp
- 2 eyelets, 14 mm in diameter (Prym)
- Decovil (Vlieseline)

Optional accessories

- Wonder Tape
- [BERNINA Straight-stitch Foot with Non-stick Sole #53](#)

CUTTING OUTER FABRIC

- 1 2 x upper bag
- 2 2 x lower bag
- 3 1 x bottom on the fold
- 4 2 x angle for lower flap

Add allowances for piece 1 and 2 only on the outer edges

which are sewn on the bottom and the facing. 2 lower flap strips 25 x 2 cm, handle approx. 150 x 7 cm, final width 3.5 cm, here without any further allowance.

Cut piece 3 additionally from Decovil, without allowances and only from the upper folded edge to the upper folded edge at the other end, which means without the facing.

CUTTING LINING

- 5 2 x bag
- 6 1 x bottom on the fold

INSTRUCTIONS

1. Cut along the centre of piece 1 vertically using a rotary cutter and a ruler. Place the lower flap strip underneath and topstitch a cut edge. Stick Wonder Tape on the long edge of the second upper bag piece, stick it on at a distance of about 1 mm to the first strip and topstitch the edge. Stick Wonder Tape on the lower edge and baste it under piece 4. Sew the edges. Complete the lower bag part and sew the back side in the same way.
2. Iron the Decovil on the bottom and let it cool off thoroughly. Sew the bottom right side on right side on the bag, minding the clasp.
3. Sew the lining bottom between the lining bag parts and leave an opening to turn it over. Sew the lining on the facing of the bag. Add the magnetic clasp and the eyelets as shown in the illustration.
4. Sew the handle wrong side on wrong side together and topstitch the folded edge. Pull the ends through the eyelets and tie knots.

