

Jumpsuit "Robin"

Model 222-30

Size 86-116



PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter). (Do not click on "Adjustment to page size"!))
2. Check the square – if it is 10×10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size. (The overview of the cut parts is on the pattern sheet.)

Important: Instructions do not include seam allowances, unless otherwise indicated!

SUPPLIES

- 0.8–1.1 m muslin, 135 cm wide
- 1 button, 15 mm
- Remnant of ribbon or tape for loop, 5 mm

OPTIONAL BERNINA ACCESSORIES

- Overlocker
- [Edgestitch Foot #10](#)
- Dual Feed or [Walking Foot #50](#)

CUTTING

- 1 1× front part on the fold
- 2 2× trousers front part
- 3 2× back part
- 4 2× rear trousers
- 5 4× heart-shaped pocket

Approx. 110 up to 130×3.5 cm bias tape for neckline and armholes, final width 1 cm.

INSTRUCTIONS

1. Close the back parts right side on right side below the slit marking. Iron the seam allowances apart up to the upper edge. Pin the ribbon for the button loop approx. 1 cm beneath the height of the upper edge under the seam allowance and sew it on there. Separate the allowances and topstitch the rear centre from the top to the bottom twice: first close to the seam and then at some distance to seam.
2. Close the shoulder seams. Sew the bias tapes right side on right side along the neckline and the armholes. Iron the tape to the inside. Fold in the narrow edges of the tape, then fold in the long allowance and topstitch it from the right. Close the side seams.
3. Close the crotch and bottom seams of the trousers. Close the inner leg seams and the side seams. Align the width of the upper trouser edge with the width of the upper part.
4. For each heart pocket, sew 2 heart cuts right side on right side together, leaving an opening of approx. 3–4 cm on one of the straight sides. **Tip:** Use the pattern piece as a sewing template. Turn the pockets inside out, iron them and sew them on close along the edge up to the marking, not flattening the ruffles above the pocket, but rather following the natural drape. Sew a bartack at the seam ends for reinforcement.
5. Sew the upper and the lower parts right side on right side together. Hem the trouser legs. Sew on a button at the rear slit.

