

Bag "Rocks"

Model 121-32

Dimensions 38×32×10 cm



PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter). (Do not click on "Adjustment to page size"!))
2. Check the square – if it is 10×10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size. (The overview of the cut parts is on the pattern sheet.)

Important: Instructions do not include seam allowances, unless otherwise indicated!

SUPPLIES

- 1 roll of imitation leather "Rocks", 50×140 cm
- 1.6 m belt strap, 40 mm
- 4 rectangular rings, 40 mm
- 4 camping snap buttons, 15 mm
- Decovil

CUTTING

1 × bag on the fold
 Bottom reinforcement 38×10 cm cut from Decovil, here without allowance.
 8 × carrier attachment 22×4 cm.

INSTRUCTIONS

1. Iron the Decovil on the bottom of the bag and let it cool off thoroughly. Narrow-topstitch the Decovil lengthwise.
Tip: For a nice interior view the Decovil may be provided with a nice cotton fabric.
2. Close the side seams of the bag. Fold the allowances apart and topstitch them. Pin the lower edge of the side seam to the centre of the bottom and close the bottom seam.
3. Fold 4 carrier attachments crosswise along the middle and topstitch the edges on top of each other. Sew the attachments right side on right side on the markings of the bag facing. Fold the upper edge of the bag along the fold and topstitch it. Punch holes in the attachment ends at a distance of 2 cm from the lower edge and the sides for the snap buttons. Fold the attachments loosely over the bag and mark the counter hole on the bag. Insert the upper parts of the snap button into the loops, the lower parts into the bag.
4. Cut the belt strap into 2 parts. Fold the remaining carrier attachments crosswise, insert one ring in each and place it over the ends of the carrier. Sew all around. Place the rings in the attachments of the bag and button it.

