

# Coat "Naomi"

## Model 322-10

Sizes 36-48



### PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter). (Do not click on "Adjustment to page size"!) )
2. Check the square – if it is 10×10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size. (The overview of the cut parts is on the pattern sheet.)

**Important:** Instructions do not include seam allowances, unless otherwise indicated!

### SUPPLIES

- 2.9–3.0 m woollen fabric, 140 cm wide
- 1.7–1.9 m lining, 140 cm wide
- Woven interlining G 700 (Vlieseline)
- 3 snap fasteners, 25 mm (Union Knopf)
- BERNINA Dual Feed or [Walking Foot #50](#)

### CUTTING OUTER FABRIC

For the dividing seam, cut through the paper pattern pieces 1 and 4 along the diagonal line.

- 1 2× upper front part
- 1 2× lower front part
- 2 2× front facing
- 3 2× pocket
- 4 2× upper back part
- 4 1× lower back part on the fold
- 4 1× rear facing on the fold
- 5 2× sleeve

We recommend allowances of 4 cm on all hems of the outer fabric and 2 cm of the lining.

### CUTTING THE LINING

On the paper pattern, tape the front and back parts together again along the slants.

- 1 2× front part up to facing line
- 4 1× back part from the facing line on the fold, adding an approx. 4 cm wide pleat for ease in the rear centre which means to place the centre approx. 2 cm away from the fabric fold.
- 5 2× sleeve



made to create **BERNINA**

## INSTRUCTIONS

1. Iron Vlieseline on the facings and let them cool off thoroughly.
2. Close the rear centre seam of the upper back parts, leaving the allowances open at the bottom towards the cross seam. Close the dividing seams of the front and back parts right side on right side and iron the seam allowances apart.
3. Place the facing of the upper edges right side on right side on pocket and sew the narrow edges together. Cut back the allowances, turn the corners inside out and press all seam allowances to the wrong side. Topstitch the pocket hem. Pin the pockets to the markings on the front part and sew them on.
4. Close the shoulder seams, leaving the allowance in the collar corner open. Close the rear centre seam of the collar. Sew the bottom edge of the collar to the neckline, cutting in the allowance at the corner. Sew in the sleeves. Close the sleeve and side seams in one go. Iron the interfacing on the allowances of the coat and the sleeve hems.
5. Close the rear pleat for ease at the top, at the waist, and from the hem for approx. 4 cm each. Sew the facings to the lining parts. Sew the lining the same way as the coat.
6. Sew the outer edges of the coat and the coat from lining right side on right side together, starting from the lower edge of the facing via the front edge and the collar, also including the lower edge of the facing. Cut back the allowances in layers and clip them along the curves.
7. Stitch the seam allowances along the long edge of the front part on the facing, close to the edge from the hem up to approx. 4 cm below the dividing seam.
8. Pull the lining sleeve wrong side on wrong side into the sleeve of the outer fabric. Pin the sleeve hems of outer fabric and lining seam on seam, pull the lining sleeve from the bottom to the inside and sew them right side on right side together. Fix the sleeve hems at the allowance of the sleeve seam.
9. At the rear neckline, pin the seams on top of each other and topstitch them from the right side in the seam shadow. Fix the shoulder seams of the lining at the allowances of the coat. Hem the lining. Hem the coat with blind stitches. Sew on the snap fasteners starting from the dividing seam at a distance of approx. 12.5 cm.

