

# Jeans dress "Kim"

Model 6923  
Sizes 36-48



## PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (do not click on "Adjustment to page size"!).
2. Check the square – if it is 10x10 cm, print out the whole cut sheet.
3. Put all pages together as shown in the overview and attach them to the boundary lines row by row. Then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size (the overview of the cut parts is on the pattern sheet). **Important:** Instructions do not include seam allowances, unless otherwise indicated.

## SUPPLIES

- 1.8–2.0 m jeans fabric, 135 cm wide
- Remnant of lining fabric
- 1.2–1.6 m elastic, 1.5 cm wide
- Felting wool in three different colours
- "Silk Finish" embroidery threads
- Embroidery accessories
- [Free embroidery file](#)
- BERNINA embroidery machine
- Jumbo Hoop, Mega Hoop, or embroidery software
- PunchWork Tool and Stitchplate
- [Edge stitch foot 10](#)

## CUTTING OUT (AFTER EMBROIDERING)

- 1 x front to fabric fold
- 4 x pocket bag, of which 2 x from lining fabric
- 1 x back to fabric fold
- 2 x back yoke to fabric fold
- 2 x sleeve
- Bias strip 30–35 x 1.5 cm,
- Drawstring 100–126 x 2.5 cm.

## INSTRUCTIONS

1. Divide, punch and embroider the fabric. Cut the pieces to size.
2. Close the darts on front. Sew the embroidered yoke right side on right side to the back; trim the seam allowances in different layers, clip in the curves, and turn it over. Sew the inner yoke section right side on right side along the neckline, trim and clip seam allowances, then turn it over.
3. Finish the front neckline with the bias tape. Sew the shoulder seams of the front part right side on right side on the yoke.
4. Fix the bottom seam allowances of the inner yoke with pins. Topstitch the yoke from the right side with a contrasting colour and the edgestitch foot.
5. Close side seams above and below the pocket mouth, continuing to sew along the pocket mouth with a long straight stitch as a basting stitch. Sew one pocket bag right side on right side on each seam allowance, leaving 1 cm open at the bottom and top. Iron the pocket bags into front part and sew them together. Undo the basting stitches. See also Tips pages in [Inspiration 67](#).
6. Pin the drawstring left side on left side on the markings. Sew along the top and bottom edge of strip, folding back the beginning and the end of the strip to leave an opening for the elastic. Pull the elastic in and sew the ends together.
7. Close the sleeve seams, gather the top shaping, and sew in the sleeves. Close elastic for the sleeve cuffs to a ring according to the forearm measurement. Hem the sleeves, attaching the elastic at the same time. Hem the dress.

