

Handbag "Tony"

Model 123-11

Dimensions approx.

32 x 19 cm



PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter). (Do not click on "Adjustment to page size"!))
2. Check the square – if it is 10x10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size. (The overview of the cut parts is on the pattern sheet.)

Important: Instructions do not include seam allowances, unless otherwise indicated!

SUPPLIES

Tip: To save material, the handles can also be attached; in this case only 0.4 m of material is needed.

- 0.9 m coated cotton fabric, 155 cm wide
- 0.9 m lining material
- Seam zip, 40 cm
- Invisible Zipper Foot #35

CUTTING (OUTER FABRIC AND LINING)

2x handbag on the fold

INSTRUCTIONS

1. Close all darts on the outer fabric and the lining. Outer fabric: Place the front and the back sides right side on right side. Close the inner sides of the handles by 3.5 cm in front of and behind the zip. Place the allowances apart and sew in the zip; refer to the video tutorial on Presser Foot #35 at www.bernina.com/foot-35. Clip the seam allowances and the zip tape.
2. Pin the outer edges of the handles and continuously the sides and bottom with the darts on top of each other and close the outer edge. Iron the allowances apart.
3. On the lining, close the inside of the handles 3.5 cm in front of and behind the zip slit and sew it together like the bag, leaving an opening between the inside darts. Iron the allowances apart. Sew the lining right side on right side along the zip tape.
4. Pull the lining handles into the open handles of the outer fabric. Check the leCut throughngths, preferably by pinning the upper darts of the lining and the outer fabric together. Pin the outer fabric and the lining at both handle ends wrong side on wrong side together. Place the outer edges of the handle seam to seam and topstitch them from the right in the seam shadow for approx. 10 cm downwards. Turn the handle inside out from the inside of the bag. Sew the upper edges and the inside of the handle right side on right side together as far as possible, clip the allowances at the lower end of the seam and cut them back in the corners. Turn the handle inside out. Sew the open inner edges of the handles together or close them by hand. Close the opening in the lining. Knot the handles.



made to create **BERNINA**