


# Shirring foot

#C24  
Overlocker



1



## Information

### Purpose

- For shirring/gathering light to medium weight, single layer fabrics.
- For smooth, balanced fabric feeding of very light, slippery single layer fabrics.
- For sewing puffing strips with overlock-, cover-, chain- or combostitches.
- For all overlock-, cover- or combostiches.

### For your safety

Before using this accessory, please read this instruction manual as well as the instruction manual of your machine carefully.

### Markings

- A Cutting line at cutting width 6
- B Right needle for OL (RN)
- C Left needle for OL (LN)
- D Right coverstitch needle RC
- E Center coverstitch needle CC
- F Left coverstitch needle LC

## Application

### Shirring

- > Thread and set the machine for an overlock-, cover-, chain- or combostitch.
- > For shirring, set the differential feed to 2.
- > For increased shirring, increase stitch length to 4.5.
- > For easing (gather to fit) of full hems or sleeve caps.

### Tip

- > To gather fabric while sewing it together with a flat piece of fabric, use the Gathering Foot.