



## Information

### **Purpose**

- For sewing buttonhole stitches, appliqués and decorative stitches.
- For sewing embroidered scalloped edges and relief effects.
- For overstitching reinforcement thread.

#### For your safety

Before using this accessory, please read the instruction manual at hand as well as the instruction manual of your machine carefully.

# **Application**

### Sewing buttonhole and decorative stitches

- > Select zigzag or decorative stitch.
- > Set the required stitch width.
- > Set the required stitch length.
- > Set the needle to the center position (see red marking on the presser foot).
- > Set the feed dog to the sewing position.

## Overstitching reinforcement thread

- > Pull the reinforcement thread through the hole in the center of the presser foot's front edge from the front to the back.
- > Select zigzag or decorative stitch.
- > Overstitch the reinforcement thread.

