


## Activity 3 Creative Sew Caddy Lettering


At the B 880 PLUS machine

With the **Monogram S** design open on the screen.

Touch the *Hoop Indicator/Select Hoop* icon, touch the Jumbo Hoop and touch the *Grid* icon until you see both the grid and the hoop's center point. Touch *Close* to return to the editing screen.




Touch Add



Touch the machine



Touch Alphabets folder



Scroll and touch Folder #15 Swiss Block




Touch the lowercase and enter "ew" and Confirm




Touch on screen and move the letters off of the S motif. Touch the Information icon.

## Activity 3 Creative Sew Caddy Lettering





Touch *Change Motif Size*, touch *Layer Panel 2* and change the size to 72%.


Touch the "i" in the breadcrumbs to return to the Information menu.



Touch *Word Art* use the Upper Multifunction Knob change the spacing to 6. Touch the "i" in the breadcrumbs to return to the Information menu.




Touch *Move Motif* and *Zoom Plus*, position the "ew" by touching on screen or using the Upper and Lower Multifunction Knobs close to the upper curve of the "S". This will make the word "Sew". Touch the "i" in the breadcrumbs to return to the Information menu.




# SUPER SEW DAY

## Activity 3 Creative Sew Caddy Lettering

Scroll and touch *Group* and then touch *Layer Panel 1*, touch *Group*. Touch the "i" in the breadcrumbs to return to the Information menu.



Touch *Zoom Minus*, position "Sew" in the lower left of the Jumbo Hoop.




Touch *Add* and touch Folder #15 Swiss Block




Enter uppercase "C" and lowercase "addy" and Confirm



Touch *Change Motif Size*, touch Layer Panel 2 and change the size to 72%. Touch the "i" in the breadcrumbs to return to the Information menu




Touch *Word Art*




Use the Upper Multifunction Knob change the spacing to 11 and use the Lower Multifunction Knob to change the arc to 36. Touch the "i" in the breadcrumbs to return to the Information menu.




## Activity 3 Creative Sew Caddy Lettering



Touch on screen and move the word "Caddy" to the lower right of the Jumbo Hoop. Touch *Zoom Plus*. Position "Caddy" so there is approximately 2 grid squares between the "Sew" and "Caddy". Touch *Zoom Minus*.



With *Layer Panel 2* selected, touch *Group* and touch *Ungroup*.




Touch the "i" in the breadcrumbs to return to the Information menu.

Touch *Zoom Plus*, touch the letters on screen and move in a scattered pattern.

Use the *Rotate Motif* to make changes to their tilt.

Position the 1st "d" above and the 2nd "d" below so there appears to be a space between the 1st "d" and the "y". This will be needed as the design is combined with other design elements.




Touch the "i" in the breadcrumbs to return to the Information menu.

Scroll down the Layer Panels and touch 2, touch *Group*, touch group until the word "Caddy" is on one layer.


## Activity 3 Creative Sew Caddy Lettering

Touch *Zoom Minus*. Touch the “i” in the breadcrumbs to return to the Information menu.


Touch *Add*



Touch the machine and touch *My Motifs*.




Touch the “Thread & Needle” motif



Move the “Thread & Needle” down in the hoop so that the tail of the thread is hanging in between the “d’s”.

*Zoom Plus* for a better view to position. Scroll and touch *Group*.




Touch *Zoom Minus*.

Touch Layer Panel 2 and touch *Group*, touch *Group* so that the word “Caddy” and the “Thread & Needle” motifs are together on *Layer Panel 2*.

# SUPER SEW DAY

## Activity 3 Creative Sew Caddy Lettering





Touch the "i" in the breadcrumbs to return to the Information menu.

Touch Layer Panel 2 and on screen move down so that the bottom of the spool of thread is aligned with the top of the "ew". Touch *Zoom Plus* if a better view is needed.


Keep the space between the "Sew" motif and the "Caddy" motif at approximately 2 grids. (This space is where the twill tie will wrap the cover.) Don't worry if this is not exact, it is designed to be random and fun!

*Zoom Minus.* Touch *Layer Panel 1* and touch *Group*, touch *Group*.

Close the Information screen.



Touch the *Selection* tab



Touch *Save the motif*



Touch the design or *Confirm* to save it to the machine.



# Activity 3

## Creative Sew

### Caddy Lettering

---

