



Activity 6 Stitch Designer Thread Loops

At the B 880 PLUS machine

Touch *Sewing Mode*




Touch the *Stitch Designer*




Designing a stitch using freehand drawing.

Touch *New*




The default is the *Pencil Tool* so that you can draw on screen.

Touch *Limit Pattern Width* (9mm lock) and disengage.




Touch *Zoom Minus 7X* or until there are no visible grid lines




Touch on screen with the Touchscreen Pen.

Start at the top of the drawing in the center and draw a curvy line and then a loop, continue with a curvy line and loop again in the opposite direction, continue with a short curve line that stops around the same y-axis as the starting point. The goal is a fluid, continuous line without lifting the touch pen until complete.

Activity 6 Stitch Designer Thread Loops



View the stitch in the preview window to the left. If you want to try again, touch *Delete* or *New*.




To edit stitches.

Touch the *Selection* icon and touch *Single Point* option.




Touch *Zoom Plus*, touch *Move*



Touch the point that you want to move, a white dot will appear when dot is active.

Points may be moved on screen with Touchscreen Pen or use Multifunction Knobs.


Move the first point and last points to the same vertical axis.



Adjust other points as desired to smooth out curves and adjust length between points.

Activity 6 Stitch Designer Thread Loops

Touch the *Scroll Up/Down* when editing to move sequentially through the individual stitch points




To add a stitch

Touch a stitch point in the area you want to add a stitch point.

Touch the *Pencil Tool*


Touch on screen to insert a stitch point. Adding additional points may smooth out the stitch, the points will need to be equally spaced.



Touch *Move* to reposition stitch points.

Touch *Automatic Stitch Run* to draw the stitch pattern on screen.

Touch *Confirm*



Touch *Presser Foot Selection*, touch *Sideways Motion Foot 40C*

Touch *Close*




Touch *Home*.




Activity 6 Stitch Designer Thread Loops


Touch *Embroidery Mode*



Touch *Selection*



Touch *New Motif*




Touch *My Motifs*



Touch new stitch just created in *Stitch Designer*




Touch the *Hoop Indicator/Select Hoop* icon, touch the *Oval Hoop* and touch the *Grid* icon until you see both the grid and the hoop's center point. Touch *Close* to return to the editing screen.



Activity 6 Stitch Designer Thread Loops

Create the Thread Loop


Touch *Information* icon. Touch *Duplicate*



Touch *Zoom Plus* for a better view of the connecting points.


Touch *Layer Panel 2* move so the thread loop is touching the motif in *Layer Panel 1*.

Touch bottom *Layer Panel* to see a view of both.




Touch *Layer Panel 1*, touch *Group*, and touch *Group*

Close the *Information* screen



Touch the *Selection* tab.



Touch *Save a motif*





Activity 6

Stitch Designer

Thread Loops

Touch the design or *Confirm* to save it to the machine.

