

## PC Requirements for BERNINA UI/BERNINA E16 OS

### Recommended Computer Requirements

- 2 GHz+ Latest Intel or AMD 32-bit (x86) or 64-bit (x64) multi core processor
- Microsoft® Windows® 10, Microsoft® Windows® 8/8.1 or Microsoft® Windows® 7 all with the latest service packs installed. (32-bit or 64-bit Editions)
- 4 GB RAM
- 80 GB hard disk space or more (at least 40 GB free disk space after installation)
- Graphics card: compatible with DirectX 10 or higher
- 512MB or higher of graphics memory (non-integrated)
- Dedicated USB port for each Melco USB Security Dongle
- Mouse or Tablet
- DVD-ROM Drive for software installation (Dual Layer DVD-ROM for Extras DVD)
- Microsoft® Internet Explorer® 10.0 or later (to access online content)
- Sound Card required for training videos
- Internet connection
- Separate/dedicated Ethernet card (DO NOT use one single Ethernet card for both the BERNINA 16 communication and Internet)

### Minimum Computer Requirements

- Intel® Pentium® 4, AMD Athlon™ 64 or AMD Opteron™
- Microsoft® Windows® 8.1 (32-bit or 64-bit Editions), all with latest service packs installed. Windows logged in user must have local admin rights
- 1 GB (32-bit) or 2 GB (64-bit) RAM
- 40GB hard disk space (at least 20GB free disk space after installation)
- Graphics card: 128MB with 1024 x 768 resolution
- Dedicated USB port for the Bernina UI/Bernina E16 OS USB Security Dongle
- Mouse or Tablet
- DVD-ROM Drive for software installation
- Microsoft® Internet Explorer® 9 or later (to access online content)
- Sound Card required for multimedia training
- Separate/dedicated Ethernet card (DO NOT use one single Ethernet card for both the Bernina 16 communication and Internet)