



- | | |
|--------------------------------------|--|
| 1 Bobbin cover | 21 Retractable spool pin |
| 2 Presser foot | 22 Upper multi-function knob |
| 3 Needle threader | 23 Lower multi-function knob |
| 4 Sewing light | 24 Handwheel |
| 5 Manual presser foot lifter | 25 Needle left/right |
| 6 Thread cutter | 26 Magnet holder for touch screen pen |
| 7 Securing | 27 Connection for power cable |
| 8 Start/Stop | 28 Power switch |
| 9 Slide speed control | 29 USB port |
| 10 Thread take-up lever cover | 30 PC-connection |
| 11 Presser foot pressure | 31 Feed dog up/down |
| 12 Thread take-up lever | 32 Connection for foot control |
| 13 Needle up/down | 33 Connection to free hand system |
| 14 Thread pretension | 34 Connection for slide-on table |
| 15 Pattern end | 35 Stitch plate |
| 16 Quick reverse | |
| 17 Needle clamp | |
| 18 Touch screen | |
| 19 Spool pin | |
| 20 Bobbin winding unit | |