

Pants "Vicky"

Model 322-26

Sizes 36–48



PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (US-Letter). (Do not click on "Adjustment to page size"!))
2. Check the square – if it is 10×10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size. (The overview of the cut parts is on the pattern sheet.)

Important: Instructions do not include seam allowances, unless otherwise indicated!

SUPPLIES

- 1.2–1.9 m knitted fabric, 160 cm wide
- 0.8–1.1 m elastic, 3,5 cm wide
- 1–1.3 m ribbon, 15 mm wide (Veno)
- 2 eyelet patches (Veno)
- Remnant of woven interlining G 700 (Vlieseline)
- 2 cord ends (Prym)
- BERNINA Dual Feed or [Walking Foot #50](#)
- Elastic sewing thread "SeraFLEX" (Mettler)
- BERNINA [Overlocker L 890](#)

CUTTING

- 1 2× front part
- 2 2× back part

Waistband 86/90/94/98/102/106/110×9 cm, final width 4.5 cm.

INSTRUCTIONS

1. Thread the overlocker for a 4-thread overlock or a 3-thread super stretch stitch. Close the side seams. Close the front and the rear centre seams and the inner leg seams.
2. Place the waistband wrong side on wrong side. Mark the front centre and define the centre of the eyelet 4,5 cm to the right and left of it, 2.2 cm below the folded edge. Cut two squares of fabric interlining with an edge length of 3.5 cm and iron them centrally behind the eyelet centres. Sew a square of 2×2 cm around the centre. Cut the hole with an allowance. Place the eyelet patches over the holes and stitch them on. Use the Zipper Foot #4 for this purpose, if necessary. Close the waistband to form a ring, leaving an opening in the inner waistband for the elastic.
3. Divide the waistband and the top edge of the trousers into quarters. Sew the outer side of the waistband slightly stretched right side on right side along the upper edge of the trousers, placing the waistband seam in the rear centre. Finish the inner long edge and pin it in place. Sew on the waistband from the right in the seam shadow. Pull in the elastic and sew it together at a comfortable width. Topstitch the upper edge of the waistband and the elastic from the top 0.5 cm wide, stretching the waistband so that it lies flat. Insert the ribbon, thread the cord into the cord ends, and knot the ribbon ends.
4. Thread the overlocker for a coverstitch. Iron up the hems of the pants and hem them.



made to create **BERNINA**