














B 700





Overview Functions and Views

	Upper thread tension
	Needle selection
	Presser foot display/Presser foot selection
	Embroidery hoop display/Embroidery hoop selection
	Stitch plate selection
	Fill level of bobbin thread








Overview System settings

	Home
	Setup Program
	Tutorial
	Embroidery consultant
	Help
	eco mode
	Back to basic setting







Overview Selection menu

	Selection embroidery motifs
	Editing embroidery motifs
	Color information
	Embroidery





Icons













	i-Dialog
	Close
	«+»
	«-»
	Back to basic setting
	Confirm
	Cancel

Overview Embroidery hoop functions



	Centering the embroidery hoop to the needle
	Moving the hoop to the back
	Moving the embroidery arm to the left
	Grid on/off
	Motif center
	Virtual positioning

Overview Editing embroidery motif






	Moving the view
	Moving the motif
	Zoom in
	Zoom out



-  **Moving the motif**
-  **Rotating the embroidery motif**
-  **Altering the size**
-  **Pinpoint placement**
-  **Mirror image left/right**
-  **Mirror image up/down**
-  **Bending text**
-  **Altering the stitch type/stitch density**
-  **Checking the motif size**
-  **Endless Embroidery**
-  **Duplicating**
-  **Deleting**

Overview changing the color

-  **Altering color/brand**
-  **Allocating thread brand**

Overview Embroidery menu



-  **Basting**
-  **Moving the hoop**
-  **Embroidery sequence control when the thread breaks**
-  **Cutting connecting stitches**
-  **Reducing color changes**

-  **Multi-colored embroidery motif on/off**
-  **Endless Embroidery**









Color indication

Administering embroidery motifs

-  **Saving the embroidery motif**
-  **Deleting**

Diverse

-  **Select USB stick**
-  **Optimal embroidery speed**
-  **Maximal embroidery speed**
-  **Adding an embroidery motif**
-  **Adding an embroidery motif**
-  **Finishing the embroidery motif**

