



Logo Creation

Touching Up a Graphic: Corel PHOTO-PAINT

By editing a picture with Corel PHOTO-PAINT Essentials, you can make changes to artwork to prepare it for one of the auto digitizing tools.

Open the file

- Open a new file.
- Switch to *Art Canvas*.
- Click on *Load Picture*. Load the graphic, PN Logo.jpg.
- Select the graphic, select *Import*; then *Enter*.
- While the picture is selected, click on the *Touch Up Picture* icon.
- The software opens Corel PHOTO-PAINT Essentials 4.



Adding color to the image

- Zoom in on the letter o of the image by selecting the *Zoom tool* and clicking and dragging around the letter.
- Select the *Eyedropper Tool* and left click on the color you wish to select from the graphic image. In this case, select white from the background color. Notice that the white color chip is now placed in the uppermost square at the bottom of the your tool icons.
- Select the *Paint Tool*.
- Make sure Custom Art Brush is selected from the brush types in the Property bar.
- From the Property bar, select the *Shape and Size* of the *Paint tool* that you wish to use. Experiment with what works for you.
- Paint color breaks in between each letter as illustrated below.



Returning to Design View

- Select *File> Finish Editing* or click on *Finish Editing* button at the top of Corel PHOTO-PAINT screen.
- When prompted to save, click *Yes*.
- To return to BERNINA Embroidery Software, select *File/Exit*.
- You may switch to *Embroidery Canvas* and process the picture for Magic Wand or Auto Digitizing.




Notes:

To avoid mistakes, zoom in on the image.



You may further paint the graphic to separate sections of each letter so that you can set specific stitch angles for each section of each letter. This makes auto digitized lettering more like a built-in font. The Add Stitch Angle/Values tool can also be used to edit the letters.



Refer to the handout, Logo Magic Wand for the steps to complete the embroidery.