


artista



- 1** Handwheel
- 2** Stitch width adjusting buttons
- 3** Stitch length adjusting buttons
- 4** Needle positioning buttons
- 5** Power switch
- 6** Feed-dog drop
- 7** Touchscreen
- 8** Bobbin case with bobbin