


activa 230



- | | |
|---|---|
| 1 Stitch card | 9 Threader |
| 2 Stitch width/Needle position/Stitch length | 10 Magnifying glass holder (for optional lens set) |
| 3 Memory | 11 Quick reverse button |
| 4 Alphabet selecting buttons | 12 Needle stop up/down |
| 5 Stitch selection buttons | 13 Half motor speed |
| 6 Standard buttonhole | 14 Pattern end button |
| 7 Free Hand System FHS (optional) | 15 Thread tension adjusting wheel |
| 8 Presser foot | |