

BERNINA
Accessory Spotlight


Decorative Pintuck Foot #46C

Created by Susan Beck

Decorative Pintuck Foot #46C is designed to add a 2-step embellishment to fabric. First, widely spaced double needle pintucks and second, decorative stitches fill the spaces between the pintucks. The acrylic sole of the presser foot offers a clear view of the stitching area.



Decorative Pintuck Foot #46C works on all current BERNINA models, those with 9mm and those with 5.5mm stitch width.



Insert a 3.0mm double needle into the machine and thread with two spools of thread (see right).



Mark a line on the fabric for the first pintuck. Following the line, stitch the first pintuck.

Position the pintuck in one of the grooves to get the desired spacing. Stitch a second pintuck.

Continue repositioning foot and aligning the pintucks in the groove until the desired number of pintucks are sewn.

Place 1-2 layers of stabilizer behind the fabric. Align the foot over the pintucks and select a decorative stitch; sew the stitch between the pintucks.

Double Needle Threading

Place one spool on the vertical pin and one on the horizontal spool pin, threading them together except in the following two areas:

- Place one thread on each side of tension disc
- Bypass the last guide with one of the threads


Note: 8 Series models must be threaded manually

Corded Pintucks

Add body and dimension to pintucks by stitching over cord. Use a narrow cord such as gimp cord, perle cotton, topstitching thread, crochet cotton, or embroidery floss. Position the cord for stitching using one of the methods below.



Thread narrow cord through bobbin area and up through hole in front of needle opening (works with models that have the type of stitch plate shown)



Another option is the Pintuck Attachment that holds the cord in front of the needle (works with all models)

Visit bernina.com: Projects • Webinars • Promotions