


Embroidery

	Home		Rotating the embroidery motif
	Setup Program		Altering the embroidery motif proportionally
	Tutorial		Mirror image left/right
	Help		Mirror image up/down
	ECO		Deleting the embroidery motif
	Upper thread tension		Checking motif size
	Presser foot display/Presser foot selection		Altering the stitch type/stitch density
	Embroidery hoop display/Embroidery hoop selection		Selecting the machine
	Stitch plate/Needle selection		Selecting the USB stick
	Feed dog up/down		Moving the hoop to the left
	Filling level of bobbin thread		Moving the hoop to the back
	Close		Parking the embroidery module for sewing mode
	Confirm		Motif center
	Cancel		Virtual positioning
	Relocating the view		
	Moving the view of the motif	Color pattern display	
	Zooming in		Selection
	Zooming out		Basting
	Relocating the motif		Moving the hoop

Embroidery



Editing



Embroidery sequence control when thread breaks



Cutting connecting stitches



Colors



Single or multi color embroidery motif



Embroidery



Loading embroidery motif



Saving the embroidery motif



Changing the thread brand



Optimal embroidery speed



Adjusting the maximum embroidering speed