BERNINA
WIFI CONNECTOR

made to create **BERNINA**

Quick Start

1 **Install BERNINA embroidery software 9**

2 **Ensure your computer has an active internet connection**

Note: the computer must be in the same wireless network to be used by the BERNINA WiFi Device

3 **Launch BERNINA WiFi connector**

Double-Click the WiFi connector icon
on the desktop or program group

W

4 **Plug the BERNINA WiFi Device
into the computer**

BERNINA

USB Type-C   USB Type-A

Ensure all lights are in 'Set-up' mode
before proceeding to Step 5

Note: The WiFi-Device might take up to 2 minutes to initialize.

5 **Run the Set-up wizard**

Click on *'Add New BERNINA WiFi Device'* and follow the 3-step set-up wizard prompts

+ Add New BERNINA WiFi Device

Ensure all lights are in *'Ready'* mode before proceeding to Step 6

6 **Plug the BERNINA WiFi Device into the embroidery machine**

BERNINA

USB Type-C

USB Type-A

Ensure all lights return to 'Ready' mode

Note: The WiFi-Device might take up to 2 minutes to initialize.

Device Overview

USB Type-C

Power

WiFi

BERNINA

Status

Modes:

Set-up Mode

Ready Mode

Documentation

For detailed set-up information, and a list of compatible BERNINA embroidery machines, refer to BERNINA WiFi Connector documentation in the BERNINA embroidery software 9 HELP menu or visit

https://www.bernina.com/v9#!support

Technical details

Standards: 802.11 b/g/n
Frequency: 2.4 GHz
Speed: 6 Mbps
Security: WEP or WPA/WPA2

Note: For best performance verify that your BERNINA embroidery machine has the latest firmware installed: https://www.bernina.com/support#!Machines

DEVICE TAG

W7593

BERNINA International AG., Steckborn, Switzerland