


Washers for Q 20



Information

Scope of delivery

- 2x Washer
- 2x Screw

Purpose

- Preparing the Q 20 on frame for use with the Ruler Work Kit.



For your safety

Before using this accessory, please read the instruction manual at hand as well as the instruction manual of your machine carefully.

Application

Mounting the washers

- > Open the hook cover. (Fig. 1)
- > Attach one washer to each of the front corners of the stitch plate frame with a screw. (Fig. 2)
- ⇒ The stitch plate frame is prepared as a support for the Ruler Base. (Fig. 3)

